



Fig 2.21 Wicken Windmill: Steering Worm

With wooden centring. Before steel brackets fitted at each end to strengthen the arrangement